


Introducción a ThingSpeak




Que es ThingSpeak?





- ThingSpeak es una aplicación para Internet de las cosas (IoT).
- ThingSpeak tiene una API para recibir y enviar datos de las cosas que se encuentran conectadas a internet usando los protocolos HTTP y MQTT
- ThingSpeak permite mostrar información generada por sensores así como la geolocalización de los mismos.
- ThingSpeak permite vincular nuestros dispositivos a redes sociales

ThingSpeak: Ejemplos



ThingSpeak: Ejemplos






https://thingspeak.com/channels/28392 Fri Apr 10 2015 21:38:57 GMT+0700 (SE Asia Standard Time)


ThingSpeak Apps





1-Create a ThingSpeak Account


https://thingspeak.com/



2-Create a ThingSpeak Channel


The second thing you want to do, is to go to the Channels tab in the Mainview and then go to My Channels.





3-Create a New Channel

New Channel




Help

Channels store all the data that a ThingSpeak application collects. Each channel includes eight fields that can hold any type of data, plus three fields for location data and one for status data. Once you collect data in a channel, you can use ThingSpeak apps to analyze and visualize it.

Channel Settings

- . Channel Name: Enter a unique name for the ThingSpeak channel.
- Description: Enter a description of the ThingSpeak channel.
- Field#: Check the box to enable the field, and enter a field name. Each ThingSpeak channel can have up to 8 fields.
- . Metadata: Enter information about channel data, including JSON, XML, or CSV data.
- Tags: Enter keywords that identify the channel. Separate tags with commas.
- Link to External Site: If you have a website that contains information about your ThingSpeak channel, specify the URL.
- Show Channel Location:
 - Latitude: Specify the latitude position in decimal degrees. For example, the latitude of the city of London is 51.5072.
 - Longitude: Specify the longitude position in decimal degrees. For example, the longitude of the city of London is -0.1275.
 - Elevation: Specify the elevation position meters. For example, the elevation of the city of London is 35.052.


4- New Channel is Ready to use



Channel Stats


Created: less than a minute ago

Entries: 0



5- API KEYS

Canal de prueba



API Requests

Write a Channel Feed



Read a Channel Feed




Read a Channel Field



Read Channel Status Updates

```
GET https://api.thingspeak.com/channels/907243/status.json?api_key
```

Test Channel



Sample Python Script

```
import sys
import urllib

# Enter Your API key here
myAPI = 'DVDTVSXTQFY8QZXT'
# URL where we will send the data, Don't change it
baseURL = 'https://api.thingspeak.com/update?api_key=%s' % myAPI

# Sending the data to thingspeak
conn = urllib.urlopen(baseURL + '&field1=%s&field2=%s' % (300, 500))
print conn.read()
# Closing the connection
conn.close()
```

